



## Display Alphabet Characters




### FRONT PANEL




WLCMONO 26

## OPERATING MANUAL


### STARTING MENU



### TIME PARAMETER



### AMPERE PARAMETER



### VOLTAGE PARAMETER

